

Index

- Actions
 - cam, 286-288
 - machine, 288-289
 - machine, All-Purpose Linotype, 468
- Adaptor, elevator, All-Purpose Linotype, 461
- Adding magazines, 37
- Adjustable mold, Universal, 21, 41, 140
 - mold liners, 140, 143
 - changing, 25, 140, 141, 143, 146, 151
- Adjustments, Linotype, 382-386
- Advertising Figure mold, 25, 41, 143
 - special, 41, 143
- Advertising lines, All-Purpose Linotype, 458
- Air cushion
 - delivery slide, 100
 - maintenance, 106
 - oscillating mechanism, Models 29 and 30, 316
 - Self-Quadder, 397
- Aligning dial, All-Purpose Linotype, 452, 463
 - and wedges, 452
- Alignment
 - adjustment of transfer, 246
 - controlled, All-Purpose Linotype, 458
 - face, 129
 - matrices, relative, 39
 - mold, 40-43
 - vertical, 129
- All-Purpose Linotype, 445-473
 - advertising lines, 458
 - aligning dial, 452, 463
 - and wedges, 458
 - aligning type face on slug, 470
 - casting interval regulator, 452
 - casting Linotype matrices, 462
 - casting matrices of other manufacture, 463
 - composing the line on the, 454
 - driving clutch, maintenance, 471
 - ejector cam, maintenance, 471
 - elevator slide, maintenance, 470
 - elevator adaptor, 461
 - equipment, 446-454
 - furniture rack, 451
 - individual type on the, 450
 - initials
 - two- or three-line, 459
 - raised, 460
 - Linotype metal for, 473
 - maintenance, 470-473
 - matrices, 447
 - matrix blocks, 461
 - matrix cabinet, 446
 - metal feeder, 453
 - molds and liners, 448
 - mold slide, maintenance, 471
 - motor, 453
 - operation, 454-470
 - overhanging work, 457
 - pot pump maintenance, 471
 - rule form system, 464
 - safeties, 467
 - slug
 - cooling attachment, 451
 - face surfacer, 450
 - maintenance, 471-472
 - trimmer saw, 450
 - maintenance, 472
 - stick aligning rail and elevator adaptor, 461
 - sticks, 448
 - table top, 453
 - visé automatic, maintenance, 470
- Alternating current motors, 437, 439
- Application of Micro-Therm control to outstanding Linotype electric metal pots, 200
- Artificial gas, plant governors, 161
- Asbestos packing for pot, 152
- Assembler, 81
 - adjustment, 385
 - belt, 11, 81
 - adjusting tension of, 81
 - block (assembler), 81
 - lubrication, 84
 - entrance, 65-66, 69-74, 79-84
 - chute finger, 81
 - maintenance, 82-84
 - revolving, 66, 79
 - star wheel, 81
 - friction clutch, 83
 - Two-in-One, 79
 - upper (oscillating) Models 29 and 30, 65, 80
 - mechanism of, 314-319
 - maintenance, 318
 - setting, 69
 - entrance front, Model 9, 364
 - front, mechanism of oscillating (upper), Models 29 and 30, 314-319
 - maintenance, 318
 - guides, 11
 - rail, 40
 - slide, 90-92
 - brake, 90
 - adjustment, 385
 - finger, 91, 99
 - maintenance, 92
- Assembling elevator, 21, 93-97
 - adjustments, 385
 - change of measure, 15
 - delivery slide release pin, 94
 - adjusting, 96
 - duplex rails, 18, 93, 95
 - finger, adjusting, 96
 - gate, maintenance, 97
 - lever link, adjustment, 97
 - maintenance, 96-97
 - matrix buffers, 95
 - replacing, 96
 - matrix detaining plates, 95
 - matrix retaining pawls, 95
 - matrix support rail, 93, 96
 - oiling, 97
 - removing, 96
 - two-letter attachment, 95
- Assembling line of matrices, maintenance of mechanism for, 412
- Attachment, simple two-letter, 114, 116-118
- Automatic ejector set, 216
- Automatic pump stop, maintenance, 417
- Automatic switch, Micro-Therm temperature control, 197
- Automatic starting mechanism, 102
- Automatic, visé, 113-114, 115
 - adjustment, 113, 120
- Auxiliary lever, first elevator, adjustment of, 111
- Auxiliary line safety, 116
- Auxiliary magazine, 60
 - elevating mechanism for, 348-353
 - method of timing, 352

- Back knife, 144
 adjustment, 148, 385
 sharpening, 149
- Back milling, matrix, 40
- Back mold wiper, 144
 care of, 151
- Back squirts, causes of, 208-209
- Bail box, 65, 74
 maintenance, 75
- Bar
 distributor, *see* Distributor bar
 first elevator slide guide intermediate, 235
 keyboard key-, 47
 second elevator, 34, 235
 vise justification, 128
- Beam, distributor
 horizontal adjustment, 262
 vertical adjustment, 262
- Bellows, expansion, *see* Expansion bellows
- Belt, assembler, 11, 81
 adjusting tension of, 81
- Bevel cut, matrix, 39
- Big Scheme of Simple Operation, The, 3-37
- Blades, Universal ejector, 213
- Blank slugs, casting, Self-Quadder, 393
- Block
 assembler, 81
 lubrication, 84
 knife, Universal, 33
 lapping, 149
 matrix slide, 36
- Blocks
 matrix, All-Purpose Linotype, 461
 mold disk locking stud, 126, 134
 adjustment, 151, 383
- Blowing of fuses, grounding, 182
- Blue Streak magazine shift, 61, 294, 343-353
- Bolt, second elevator adjusting, 242
- Box
 ball, *see* Ball box
 distributor, *see* Distributor box
 spaceband, *see* Spaceband box
- Brake, assembler, slide, 90
- Bridge indicators, Models 29 and 30, 312
 adjustment of, 319
- Bridge notch, matrix, 38, 365-369
- Bridges
 adjustable, Models 29 and 30, 312
 matrix, 370-372
 Model 9, 371
 Models 25 and 26, 370
 Models 29 and 30, 370
- Buffer
 assembling elevator matrix, 95
 replacing, 96
 distributor shifter, 255
 spaceband, 95
 maintenance, 92
- Burner,
 Gas, *see* Gas burner
 Linotype gasoline-kerosene, with
 pressure tank, 163
- Button, keyboard key, 47
- Cabinet, matrix, All-Purpose Linotype, 446
- Cam
 actions, 286-288
 and yoke, keyboard, cleaning, 53
 first elevator, 108, 111
 keyboard, 47
 removal of, 9
 mold slide, 155
 pin, keyboard, 47
- Cam—*continued*
 pot return, 155
 shoes, mold turning, 135, 136
 stop strip, keyboard, 47
 to replace, 55
 yoke, keyboard, 47
 trigger, 47
- Cams, main, 286-288
 maintenance, 289
 All-Purpose Linotype, 469
 Cam Actions and Machine Actions, 286-289
- Capacity of metal pot, 164
- Casting
 from Linotype matrices on All-Purpose
 Linotype, 462
 from other hand-set matrices on All-Purpose
 Linotype, 463
 interval regulator, All-Purpose Linotype, 452
 mechanism, 3
- Catalog of special supplies, 442
- Causes of transpositions, 82-84
- Centering lines, Self-Quadder, 392
- Change of measure
 assembling elevator, 15
 delivery slide, 15
- Changing length of line, 140, 141, 143, 146, 151
- Changing mold liners, 25, 140, 141, 143, 146, 151
- Channel, magazine, 57
- Channel Chooser, 321-327
 operating sequence, 325
 setting the, 325
- Channel entrance
 maintenance, 418
 Two-In-One single distributor Linotype
 distributor bar positioning mechanism, 341
 distributor safety, 341
 revolving the, 342
 to open, 342
- Character
 auxiliary position of matrix, 38
 normal position of matrix, 38
- Charts, tooth combination and lug, 271-275
- Chute finger, 15, 40
 assembler entrance, 81
- Clapper switch, electric pot, 171
- Cleaner, matrix reference, Dixon's, 46
- Cleaner and holder, Perfect, 45
- Cleaning matrices, 45
- Cleaning and oiling, 421-435
- Clutch
 and driving pulley, 276-278
 maintenance, 283-285
 collar, clearance, 284
 distributor, Model 9, 362
 distributor, on single distributor
 Linotypes, 264-268
 maintenance, 267-268
 driving, adjustment, 382
 failure to disengage, 285
 friction clutch arms, 284
 leathers, 284
 main driving, All-Purpose Linotype,
 maintenance, 471
 star wheel friction, 83
- Circuits, connecting electric metal pot to
 various, 176
- Coil, magnetic switch kick-out, 172
 panel box resistance, 172
- Combinations, tooth, on bar and
 matrices, 269-275
- Composing the line, All-Purpose Linotype, 454
- Connecting link, first elevator, 110, 115

- Control**
equipment, 42-em electric metal pot, 375-379
Micro-Therm
 electric metal pot, 31, 196-206, 210, 378-379
 gas temperature, 160-161, 162
 panel, 171, 174
 testing, 184
 wiring, 184
Controlled alignment, All-Purpose Linotype, 458
Cooler, Thermo-Bio Mold, 440
Cooling, slug, All-Purpose Linotype, 451
Cover, pot, 166
Crucible heat control, Micro-Therm,
 see Micro-Therm
Crucible heater
 Lino-Therm, 194-196
 No. 1, removal of, 192
 replacement, 192
 No. 2, removal of, 185
 replacement of, 185
Crucible heaters
 connected in series, 168
 in parallel, 168
 Nos. 1 and 2, 167, 168
Cut
 matrix bevel, 39
 matrix clearance, 39
- Decimal equivalents of type bodies, 443
Definitions, electrical, 174-175
Delivery air cushion, 100, 106
Delivery channel, 104
Delivery pawl, delivery slide, 100
Delivery slide, 98-107
 adjustments, 384
 air cylinder (cushion), 100
 automatic starting mechanism, 102
 change of measure, 15
 delivery pawl, 100
 long finger, 99
 adjustment, 105
 friction, 106
 lubrication, 106
 maintenance, 104-107
 releasing pin, 94, 101
 adjustment, 96
 removal of, 106
 retaining pawls, 104
 short finger, 99
 travel, adjustment of, 101-105
Diagrams, wiring, 174, 184, 186-192, 201, 202, 204
 Micro-Therm controlled electric metal
 pot, 199, 200, 201
Dial, aligning, All-Purpose Linotype, 463
 and wedges, All-Purpose Linotype, 452
Direct current circuits (two and three wire),
 connecting pot to, 176
Direct current motors, 437, 438
Dimensions of matrix, 39
Disk, mold, 21
Dismantling a Linotype, 386-390
Display mold, 25
 or headletter mold, one-letter, 142
 two-letter, 142
Display mouthpiece, 159
Distinguisher, font, 35, 255
 to replace, 262
Distribution of matrices, 250
Distributor
 back screw, to open, 262
 and channel entrance safety, on Two-In-One
 single distributor Linotypes, 341
Distributor—continued
 bar, 259
 and channel entrance, positioning
 mechanism on single distributor
 Two-In-One Linotypes, 332-342
 maintenance of, 341
 sectional, 291, 294
 tooth combinations, 269-275
beam, adjustment, 386
 horizontal adjustment of, 262
 vertical adjustment of, 262
box, 35
 adjustment, 385
 bar, 252
 bar point maintenance, 260
 font distinguisher, 255
 to replace, 262
 lower, for multiple distribution, 297-301
 timing, 308-309
 matrix lift, 35, 252
 adjustment, 261, 385
 maintenance, 261
 rails, 252
 maintenance, 261
 single distributor Linotypes, 250-256, 260-262
 maintenance, 260-262
 testing, 261
 to remove, 260
 upper for Models 25 and 26, 296, 297, 298
 upper for Models 29 and 30, 314
clutch
 lubrication, 268
 maintenance, 267-268
 Model 9, 362
 removal of, 267
 single distributor Linotypes, 264-268
 spring tension, 268
 starting distributor, 267
 maintenance, 418
 multiple, Models 29 and 30, 312-314
 Model 9, maintenance of, 363-364
 Models 25 and 26, maintenance, 308-309
oil, 421
 use sparingly, 263
screw bearings, use of oil, 418
screw guard, 259
 adjustment, 384
shifter, 244
 maintenance, 249
 buffer, 255
 slide, 246
 maintenance, 249
single distributor Linotypes, 257-263
 maintenance, 262-263
spiral automatics, 258
 maintenance, 263
Dixon's matrix reference cleaner, 46
Double e (ee) attachment, 59
Double plunger, 42-em, 374
Doublets, matrix, 411
Driving
 clutch, adjustment, 382
 mechanism, 276-278, 283-285
 shaft, to remove, 283
 starting and stopping mechanism, 276-285
 maintenance, 283-285
Duplex Display matrices, 39
Duplex rails, assembling elevator, 93
 first elevator jaw, 108
Dynamic thermometer, 168
 fluttering switch, 183
 to remove or replace, 193

- ee (double e) attachment, 59**
Ejection mechanism, maintenance, 417
Ejector, Universal, 32, 137, 213-218
 blades, 213
 adjustment, 385
 replacement of, 217
 cam, All-Purpose Linotype, maintenance, 471
 42-em Linotype, 373
 lever
 adjustable pawl, 217
 removal of, 217
 adjusting stroke of, 217
 maintenance, 216-218
 set, automatic, 216
 slide, removal of, 216
Electric and gas metal pots, 152-212
 maintenance, 206-212
Electric metal pot, 163-212
 application of Micro-Therm control to
 outstanding Linotypes, 200
 equipped with envelope heaters and
 mechanical thermostat
 heats up slowly, 179
 operation, 177
 overheats, 180
 replacement of parts, 185-194
 troubles and testing, 178
 will not heat up, 179
 42-em, 375-379
 Lino-Therm heaters, 378-379
 Micro-Therm control, 378-379
 heaters, envelope, 164, 167
 Lino-Therm, 31, 194-196
 for 42-em Linotype, 378-379
 installation of, 175
 instruction book, 152
 interchangeability with gas metal pot, 163
 with envelope heaters and dynamic
 thermometer or mechanical thermostat,
 152-159, 163-194, 206-209, 210, 211-212
 replacement of parts, 185-194
 with Lino-Therm heaters and Micro-Therm
 control, 152-159, 194-210
Elevating mechanism
 for auxiliary magazines, 348-353
 for main magazines, 344-348
Elevator
 adaptor and stick aligning rail, All-Purpose
 Linotype, 461
 assembling, *see* Assembling elevator
 first, *see* First elevator
 second, *see* Second elevator
 slide, All-Purpose Linotype, maintenance, 470
 transfer and spaceband shifter cam, 238
 strokes of, 239
 transfer lever, 237
 adjustment, 384
Entrance
 assembler, 65-66, 69-74, 79-84, *see also*
 Assembler entrance
 channel, *see* Channel entrance
 magazine, 59
Envelope heaters, 164, 167
 and control equipment for 42-em electrical
 metal pot, 375-378
Escapement, 9, 11, 62
 action of, 62
 maintenance, 76, 411
 mechanisms, 62-78
 Model 9, 355-358
 Models 8 and 14, 63, 66-69
 Models 27 and 28, 66
 Models 29 and 30, 65-74
 Models 31 and 32, 32, 66, 69, 71
Escapement—continued
 pawl, 62
 plunger, 62
 straight-line, importance of, 293
 verge, 62
Expansion bulb and bellows, Micro-Therm
 temperature control
 gas, 160
 electric, 197
Expansion element or rod, mechanical
 thermostat, electric metal pot, 169
Face alignment, 129
Failure
 of magnet switch resistance coils, 173
 of slug to eject, 218
Feeder, metal
 Kendall, 439
 Margach, 440
Figure advertising mold, 25, 41, 143
 Special, 41, 143
Filling piece, first elevator slide, 114
Finger,
 assembler entrance chute, 81
 assembler slide, 91, 99
 assembling elevator duplex rail,
 adjustment, 96
 chute, 15, 40
 Finger key, quick mixing, 310, 317
First elevator, 21, 108-122
 adjustments, 383
 for normal position, 111
 auxiliary lever, adjustment, 111
 cam, 108, 111
 connecting link, 110, 115
 adjustment, 383
 intermediate bar, adjustment, 385
 jaw, 108, 109
 duplex rail, 108
 maintenance, 121-122, 413
 Self-Quadder, cleaning or repairing, 403
 lever link, 110, 115
 line stop, 108
 maintenance, 122
 maintenance, 119-122
 movement of, 111
 pawls, 108
 slide, 108, 115
 adjustment, 112
 filling piece, 114
 gibs, 111
 adjustment, 383
 guide, adjustment, 385
 intermediate bars, 235
 pawls, 235
 lubrication, 122
 maintenance, 413
 safety, 118
First justification, 126-130
Fixed indentation with Self-Quadder, 391
Fluttering switch
 dynamic thermometer, 183
 mechanical thermometer, 184
Font
 distinguisher, 35, 255
 to replace, 262
 slot, matrix, 38, 365
Forked levers, to test clearance of, 285
45-point alignment matrices, 39
42-em Linotype, 373-381
 ejector, 373
 metal pot and double plunger, 374
 maintenance, 380-381, 420

- 42-em Linotype—continued**
 metal pot and double plunger—*continued*
 envelope heaters and control
 equipment, 375-378
 Lino-Therm heaters and Micro-Therm
 control, 378-379
 mold disk and molds, 373
 pot mouthpiece wiper, 379
- Frame**
 keyboard cam yoke, to remove, 53
 magazine, setting of, 74
 vise, 123-126
- Friction clamp, mold driving pinion shaft, 136**
- Friction clutch, star wheel, 83**
- Front**
 assembler, 65-66, 69-74, 79-84, *see also*
 Assembler entrance
 entrance, Model 9, 364
 oscillating or upper, 65, 80, 310
 maintenance, 318
 mechanism of, 314-319
 setting of, 69
 guide holder, pivoting, 65, 310
 mold wiper, 145
 movable and magazines, Model 9,
 adjustment, 364
 revolving, on single distributor Two-in-One
 Linotypes, 66, 79, 321
- Furniture rack, All-Purpose Linotype, 451**
- Fuses**
 blow, grounding, 182
 electric metal pot, 172
 mouth and throat heater circuit, 172
- Galley, 33, 226-231**
- Inclined, 228, 229**
 maintenance, 231
 reversible, Hebrew, 228
 vertical, 226
- Gas**
 and electric metal pots, 152-212
 maintenance, 206-212
 burner, 159-163
 governor, thermostatic, 159-160, 210
 metal pot, 159-163
 maintenance
 Micro-Therm, 211
 thermostat, 210
 plant governors for,
 artificial, 161
 natural, 163
 temperature control,
 Micro Therm, 160-161, 162, 211
 thermostat, 159-160, 210
- Gasoline-kerosene burner with pressure
 tank, 163**
- Gate, assembling elevator, maintenance, 97**
- General maintenance, 410-420**
- Gibs, first elevator slide, 111**
- Governors, plant**
 artificial gas, 161
 natural gas, 163
- Graphite, Dixon's No. 635, 43**
- Grease, Linotype, 421**
- Grooves, matrix lightening, 39**
- Ground (grounded circuit), 178**
- Grounding, fuses blow, 182**
- Guard, distributor screw, 259**
- Guide, mold cap, 139**
- Guides, assembler, 11**
- Hair lines, 120**
 to prevent, 43
- Hand shift of magazines on Models 25
 and 26, 301-302**
- Head-letter or display mold**
 one-letter, 142
 two-letter, 142
- Heaters,**
 for electric metal pot
 envelope, 164, 167, 192
 Lino-Therm, 31, 194-196
 for 42-em Linotype, 378-379
 gas, *see* Gas burner
- Hebrew galley, 228**
- Holder**
 and cleaner, matrix (Perfect), 45
 pivoting front guide, 65, 310
- Horizontal transfers, 235, 244**
- How to take down a Linotype, 386-390**
- Humming, magnetic switch, 183**
- Identification numbers, matrix, 372**
- Inclined galley, 228, 229**
 maintenance, 231
- Indentation, fixed, with Self-Quadder, 391**
- Indicating lamps, Micro-Therm temperature
 control, 197**
- Indicators, bridge, Models 29 and 30, 312**
 adjustment, 319
- Individual type on the All-Purpose Lino-
 type, 450**
- Initials**
 two- or three-line, All-Purpose Linotype, 459
 raised, 460
- Installation of electric metal pot, 175**
- Instruction book, Linotype electric metal
 pot, 152**
- Instructions for operating Linotype
 Self-Quadder, 392**
- Intensifier, Pierson, pot pump spring, 157, 158**
- Interchangeability of electric metal pot with
 gas metal pot, 163**
- Intermediate channel, 235**
 front plate extension, 236, 237
- Invar steel rod, thermostat gas governor, 159**
- Jacket and pot crucible, 152-159**
- Jaw, first elevator, 108, 109**
 maintenance, 121-122
- Jaws, vise, 126, 127, 128**
- Justification, 126-131**
 and vise jaw, maintenance, 131-132
 bar, 128
 care of, 131
 first, 126-130
 imperfect, 131
 lever, 127
 mechanism, general maintenance, 414
 rods
 and bar, care of, 131
 lubrication, 132
 second, 130
 stop levers, Self-Quadder, adjustment of, 405
 wedge, adjusting, 131
- Keeper, mold, 139**
- Kendall metal feeder, 439**
- Kerosene-gasoline burner with pressure
 tank, 163**
- Key, quick mixing finger, 310, 317**
- Key bar, keyboard, 47**
 cleaning, 55

- Keyboard, 3, 7, 47-56**
 cam, 47
 oil, 421
 pin, 47
 removing, 9
 stop strip, 47
 replacing, 55
 yoke, 47
 cleaning, 53
 frame, removing, 53
 spring, 51
 trigger, 47
 keybar
 cleaning, 55
 weight, 47
 keybutton, 47
 key lever, 47
 cleaning, 55
 maintenance, 53-56
 oil, 421
 overthrow, 51
 practice, 441
 reassembling, 56
 rod (reed), 47, 63
 lever slide, Two-in-One Linotype
 Models 8, 14, 25 and 26, 327-332
 Models 29 and 30, 315
 rubber roll, 47
 replacing, 54
 supplemental, 440
 upper guide, adjustment, 386
 yokes and cams, cleaning, 53
Keybutton, keyboard, 47
Key lever, keyboard, 47
 cleaning, 55
Knife
 back, 144
 adjustment, 148
 sharpening, 149
 block, Universal, 33, 219-225
 maintenance, 223-225, 417
 old style, 222
 quick-opening advertising figure, 440
 wiper, 118
Knives, left- and right-hand trimming,
 adjusting, 223-225
 sharpening, 225
Lamp
 in series, testing electric metal pot, 178
 indicating, Micro-Therm temperature
 control, 197
 use of, as resistance, 172
Lapping block, 149
Leads and slugs, thickness of, 443
Leathers, clutch, 284
Left-hand vise jaw
 detent operating lever, Self-Quadder, 397
 operating lever, Self-Quadder, 396
Length of line change, 140, 141, 143, 146, 151
Lever, keyboard key, 47
Lift, matrix
 adjustment, 308
 maintenance, 261
Line, composing the, All-Purpose Linotype, 454
Line delivery slide, see Delivery slide
Liners
 and molds, 139-144, 145-146
 All-Purpose Linotype, 448
 changing, 140, 141, 143, 146, 151
 mold, 21
 recessed mold, 141
Line stop, first elevator, maintenance of, 122
Lines, matrix face, 39
- Link**
 assembling elevator, adjustment of, 97
 first elevator connecting, adjustment, 383
 first elevator lever, 110, 115
Lino-Saw, Mohr, 436
Lino-Therm heaters, 31, 194-196
 42-em, 378-379
 with Micro-Therm control, 194-210
Linotype
 adjustments, 382-386
 All-Purpose, see All-Purpose Linotype
 42-em, 373-381
 gasoline-kerosene burner with pressure
 tank, 163
 grease, 421
 how to dismantle, 386-390
 Keyboard Operation, 441
 metal, 444
 correct operating temperature, 210
 motors, 437-439
 a.c., 439
 d.c., 438
 oil, 421
 Self-Quadder, 391-409
 instructions for operating, 392
 maintenance, 393-409
 slug, 5
 handling, 6
 Locking screws, vise, 123
 Locking stud block, mold disk, 134
 adjusting, 151
 Lock-up, 118
 testing, 206
 Logotype matrices, 39
 Long finger, delivery slide, 99
 adjustment, 105
 friction, 106
 Lower distributor box, for multiple
 distributors, 297-301
 timing, 308-309
 Lower stopping lever, adjustment, 382
 Lubricants, Linotype approved, 421
Lubrication,
 assembler block, 84
 first elevator slide, 122
 general, 421-435
 justification rods, 132
 Lug and tooth combination charts, 271-275
 Lugs, matrix, 38
 repairing damaged, 45
Machine actions, 288-289
 All-Purpose Linotype, 468
Magazines, 3, 57-78
 addition of, 37
 adjusting on Models 25 and 26, 309
 and movable front, Model 9, 364
 auxiliary, 60
 elevating mechanism for, 348, 353
 method of timing, 352
 before removing, from Linotype, 419
 channels of, 57
 entrance, 59
 hand shift on Models 25 and 26, 301-302
 locking strip, 419
 main, elevating mechanism for, 344-348
 maintenance, 419
 power shift on Models 25 and 26, 301-308
 removing, 76, 419
 safety latch, 419
 setting of bottom, 74
 sequences possible with Channel Chooser, 325
 shift, Blue Streak, 61, 294
 mechanism, 343-353

- Magazines—*continued*
 split, 59
 Two-in-One Linotype, arrangement of, 325, 327
- Magnetic switch, electric metal pot, 171
 humming, 183
 kick-out coil, 172
 resistance coils, failure of, 173
- Magneto, testing, electric metal pot, 178
- Main magazines, elevating mechanism for, 344-348
- Maintenance
 All-Purpose Linotype, 470-473
 assembler entrance, 82-84
 assembler slide, 92
 assembling elevator, 96-97
 assembling elevator gate, 97
 automatic pump stop, 417
 bail box, 75
 channel entrance, 418
 channel entrance and distributor bar safety mechanism on single distributor Two-in-One Linotypes, 341
 cleaning and oiling, 421-435
 delivery air cushion, 106
 delivery slide, 104-107
 distributor, 418
 Model 9, 363-364
 Models 25 and 26, 308-309
 distributor bar and channel entrance mechanism on single distributor Two-in-One Linotypes, 341
 distributor box matrix lift, 261
 distributor clutch, 267-268
 distributor shifter and slide, 249
 driving clutch, All-Purpose Linotype, 471
 ejector, 216-218, 417
 ejector cam, All-Purpose Linotype, 471
 electric and gas metal pots, 206-212
 elevator slide, All-Purpose Linotype, 470
 entrance, mechanism of oscillating (upper), 318
 entrance, oscillating or upper assembler, 318
 escapements, 76, 411
 first elevator, 119-122
 jaw, 121-122
 line stop, 122
 slide and jaw, 413
 42-em Linotype, 380-381
 gas and electric metal pots, 206-212
 gas metal pot thermostat, 210
 general, 410-420
 42-em Linotype, 420
 justification, 414
 rods and bar, 131
 keyboard, 53-56
 knife block, Universal, 223-225, 417
 line delivery slide, 412
 Linotype Self-Quadder, 393-409
 lubrication, 421-435
 magazine, 419
 mechanical thermostat, electric metal pot, 211
 mechanism for assembling a line of matrices, 412
 metal pot, 415
 Micro-Therm control
 for electric metal pot, 210
 for gas metal pot, 211
 mold, 414
 mold disk and mold slide, 147-151
 mold disk, 147-151, 414
 mold disk guide support screw, 151
 mold slide, 147-151
 mold slide, All-Purpose Linotype, 471
- Maintenance—*continued*
 mold wipers, 415
 mouthpiece, 206
 multiple distributor Linotype, 420
 oiling and cleaning, 421-435
 oscillating (upper) assembler front, 318
 oscillating mechanism for, 318
 plural distributor Linotype, 420
 pot mouthpiece wiper, 416
 pot pump, All-Purpose Linotype, 471
 pot pump plunger, 208
 pulley, driving, 285
 pump stop, 417
 rails, distributor box, 261
 second elevator bar, 248-249
 Self-Quadder, 393-409
 slug face surfacer, All-Purpose Linotype, 471-472
 slug saw trimmer, All-Purpose Linotype, 472
 spaceband, 43, 412
 box, 87-89
 buffer, 92
 spiral automatics, 263
 starting and stopping mechanism, 283, 285
 transfer mechanism, 246-249, 417
 Two-in-One single distributor Linotype, 420
 Universal ejector, 216-218
 Universal knife block, 223-225, 417
 vise, 415
 and justification, 131-132
 automatic, 415
 All-Purpose Linotype, 470
 Manual starting and stopping, 281-282
 Margach metal feeder, 440
 Marking, matrix references, 39
- Matrices
 All-Purpose Linotype, 447
 described, 3
 doublets of, 411
 Duplex Display, 39
 failure to drop, 410
 45-point alignment, 39
 hair lines, preventing, 43
 Linotype, casting on All-Purpose Linotype, 462
 logotypes, 39
 maintenance of mechanism for assembling, 412
 oil, effect of excessive use of, 46
 one-letter, 38
 ordering, 442
 other manufacture, casting on All-Purpose Linotype, 463
 relation to molds, 40-43
 relative alignment of, 39
 transposition of, 410
 two-letter 18- and 24-point, 39
- Matrix, 38-46
 back milling, 40
 bar point slot, 38, 254
 bevel cut, 39
 bevel notch, 39
 blocks, All-Purpose Linotype, 461
 bridges, 370-372
 Model 9, 371
 Models 25 and 26, 370
 Models 29 and 30, 370
 bridge notch, 38, 365-369
 cabinet, All-Purpose Linotype, 446
 character
 auxiliary position, 38
 normal position, 38
 cleaning, 45

- Matrix**—*continued*
 clearance cut, 39
 delivery belt, 81
 adjustment, 385
 detent, Self-Quadder, 396
 dimensions, 39
 face lines, 39
 font slot, 38, 365-371
 guard safety, adjustment, 386
 holder and cleaner, Perfect, 45
 identification numbers, 372
 lift, distributor box, 35, 252
 adjusting of, 308
 maintenance, 261
 stop, 418
 lightening grooves, 39
 lugs, 38
 charts of, 271-275
 repairing damaged, 45
 punching, depth of, 40
 release of, 9, 47
 reference cleaner, Dixon's, 46
 reference marking, 39
 side wall, 40
 slide, 36
 block, 36
 teeth, 35, 38
 care of, 44
 tooth combination and lug charts, 269-275
 triangle number, 39
- Mechanical thermostat, electric pot, 164, 169**
 maintenance, 211
 fluttering switch, 184
 to remove or replace, 193
- Metal, Linotype**
 correct operating temperature for, 210
 feeder, 439-440
 All-Purpose Linotype, 453
 for All-Purpose Linotype, 473
 pot, *see* Pot, metal
- Micro-Therm control**
 application to outstanding Linotype electric
 metal pots, 200
 crucible heat, 199
 electric metal pot, 31, 196-206, 210, 378-379
 automatic switch, 197
 expansion bulb and bellows, 197
 for mouthpiece, 199
 for pot crucible, 199
 42-em Linotype, 378-379
 indicating lamps, 197
 maintenance, 210
 wiring diagrams of, 199, 200, 201
 with Lino-Therm heaters, 194-210
 gas metal pot, 160-161, 162
 calibrations, 211
 expansion bulb and bellows, 160
 maintenance, 211
 mouthpiece heat, 199
- Milling, back, matrix, 40**
- Miscellaneous, 436-444**
- Mixer Linotypes**
 Models 25 and 26, 295-309
 Models 29 and 30, 310-319
- Mixing**
 finger key for quick, 310, 317
 faces on the Linotype,
 Model 9, 355
 Models 25 and 26, 301
 Models 29 and 30, 310-311
- Model 9, 354-364**
 adjustment of magazines and movable
 front, 364
 assembler entrance front, 364
- Model 9—continued**
 distributor
 clutch, 362
 maintenance, 363-364
 distributing mechanism, 358-364
 escapement mechanism, 355-358
 matrix bridges, 371
 mixing faces, 355
- Models 8 and 14, 290, 292, 294**
 escapement mechanism, 63, 66-69
 Two-in-One, Keyboard rod lever slide
 shifting mechanism, 327-332
- Models 25 and 26, 295-309**
 adjusting the magazines, 309
 hand shift of magazines, 301-302
 maintenance of distributor, 308-309
 matrix bridges, 370
 mixing faces, 301
 power shift of magazines, 301-308
 Two-in-One, 320
 keyboard rod lever slide shifting
 mechanism, 327-332
 upper distributor box, 296, 297, 298
- Models 27 and 28, 290-292, 294**
 escapement mechanism, 66
- Models 29 and 30, 310-319**
 adjustable bridges, 312
 bridge indicators, 312
 adjustment of, 319
 distributor box, upper, 314
 entrance, oscillating (upper) assembler, 65, 80
 setting, 69
 mechanism of, 314-319
 escapement mechanism, 65-74
 maintenance, 318
 matrix bridges, 370
 mixing faces, 310-311
 multiple distributor, 312-314
 Two-in-One, 320
 keyboard rod lever slide shifting
 mechanism, 315
- Models 31 and 32, 292-294**
 escapement mechanism, 66-69, 71
 Two-in-One, 321-327, 332-342
- Models, Two-in-One, 66-69, 294, *see also***
 Two-in-One Models
- Modern Newspaper, The, 441**
- Mohr Lino-Saw, 436**
- Mold**
 advertising figure, 25, 41, 143
 alignment, 40-43
 body, 139
 cam lever eccentric pin, Self-Quadder,
 adjustment of, 405
 cam lever, "resilient", Self-Quadder,
 adjustment of, 407
 cap, 139
 guide (post), 139
 cooler, Thermo-Blo, 440
 disk, 21, 133-137
 and molds, 42-em, 373
 care in pulling forward, 142
 guide support screw, 137
 maintenance, 151
 locking stud block, 126, 134
 adjustment, 151, 383
 maintenance, 147-151, 414
 mold and mold slide, 133-151
 pinion, 134
 display, or head-letter, 25
 one-letter, 142
 two-letter, 142
 driving pinion shaft friction clamp, 136
 adjustment, 384

- Mold—*continued*
 keeper, 139
 liners, 21, 140, 143
 changing, 25, 140, 141, 143, 146, 151
 maintenance, 414
 mold disk and mold slide, 133-151
 maintenance, 147-151
 recessed, 23, 141
 slide, 137-139
 adjustment, 149, 383
 All-Purpose Linotype, maintenance, 471
 cam, 155
 42-em Linotype, 373
 maintenance, 147-151
 means of connecting and disconnecting, 138
 mold and mold disk, 133-151
 removal of, 151
 special advertising figure, 41, 143
 turning
 bevel pinion adjustment, 383
 cam
 adjustment, 383
 shoes, 135, 136
 mechanism, adjustment, 147
 segments, 134, 136
 universal adjustable, 21, 41, 140
 mold liners, 140, 143
 changing, 140, 141, 143, 146, 151
 wiper,
 back, 144
 front, 145
 maintenance, 151, 415
- Molds, 21
 and liners, 139-144, 145-146
 All-Purpose Linotype, 448
 42-em Linotype, 373
 relation to matrices, 40-43
 six-mold disk
 24½-em, 145
 30-em, 146
- Motors, Linotype, electric, 437-439
 a.c., 439
 All-Purpose, 453
 d.c., 438
- Mouth heaters, electric metal pot, 167, 168
 and throat heaters, connected in series, 168
 removal of, 192
 replacement of, 192
- Mouthpiece, pot, 158
 display, 158, 159
 heat control,
 Micro-Therm, 199
 rheostat, 172
 gets too hot or cold, 182
 will not heat, 181
 maintenance, 206
 vents, 159
 wiper, 439
 maintenance, 416
- Multiple distributor Linotype
 maintenance, 420
 Model 9, 358-364
 Models 25 and 26, 295-309
 Models 29 and 30, 310-319
 Two-in-One, 320
- Multiple key rod (ee) attachment, 59
- Natural gas, plant governors, 163
 Newspaper Makeup, 441
 Normal position, first elevator, adjustment
 for, 111
- Notch, matrix bevel, 39
 Notch, matrix bridge, 38, 365-372
- Number, matrix triangle, 39
 Number 1 crucible heater, 192
 Number 2 crucible heater, 185
- Oil
 effect on matrices of excessive use, 46
 keyboard and distributor, 421
 keyboard cam, 421
 Linotype, 421
 use of, in distributor screw bearings, 418
- Oiling
 and cleaning, 421-435
 assembling elevator, 97
 Old style knife block, 222
 maintenance, 223-225
- One-letter display or head-letter mold, 142
 One-letter display matrices, 38
 One-turn, Blue Streak, magazine
 shift, 294, 343-353
- Open (open circuit), 175, 178
 Operating sequences with Channel
 Chooser, 325
- Operation, All-Purpose Linotype, 454-470
 Operation, Big Scheme of Simple, 3-37
- Ordering
 matrices, 442
 parts, and supplies, 442
- Oscillating (upper) assembler entrance,
 65, 80, 310
 driving mechanism, 314-319
 maintenance, 318
 maintenance, 318
 setting, 69
- Overhanging slug, 143
 Overhanging work, All-Purpose Linotype, 457
 Overthrow, keyboard, 51
- Packing for pot, asbestos, 152
 Panel box, electric metal pot, 164, 171
 testing, 184
 wiring, 184
- Parallel connection, crucible heaters in, 168
 Parts and supplies, ordering, 442
- Pawl
 assembling elevator matrix retaining, 95
 delivery slide retaining, 104
 escapement, 62
 first elevator, 108
 slide guide intermediate bar, 235
 spaceband lever, adjustment of, 248
 transfer safety, adjustment, 248
- Perfect matrix holder and cleaner, 45
 Piece, first elevator slide filling, 114
 Pierson pot pump spring intensifier, 157-158
 Pin, keyboard cam, 47
- Pinion
 mold disk, 134
 driving shaft, 283
- Pivoting front guide holder, 65, 310
- Plant governors
 artificial gas, 161
 natural gas, 163
- Plate, assembling elevator matrix
 detaining, 95
- Plunger,
 escapement, 62
 pot pump, 152, 208
- Plural distributor, *see* Multiple distributor
 Point system, 442
 Post, mold cap, 139
- Pot, 30
 adjustment, 384
 asbestos packing for, 152
 capacity of, 164

- Pot—continued**
 cover, 166
 crucible and jacket, 152-159
 crucible heat control, Micro-Therm, 199
 electric, 163-212
 Lino-Therm heaters, 31, 194-196, 378-379
 Micro-Therm control, 31, 199
 42-em Linotype, 375-379
 gas, 152-163
 lever, 155
 eye bolt, adjustment, 384
 Lino-Therm heaters for electric,
 31, 194-196, 378-379
 lock-up, testing, 206
 maintenance, 415
 Micro-Therm control of electric, 31, 199
 application to outstanding machines, 200
 mouthpiece, 158
 wiper, 439
 42-em, 379
 maintenance, 416
 pump
 All-Purpose Linotype, maintenance, 471
 cam roll, 155
 lever spring, 155
 plunger, 152
 double plunger, 42-em Linotype, 374
 maintenance, 208
 spring, Pierson Intensifier, 157-158
 stop, 152-158
 adjustment, 386
 and right hand vise jaw, 154
 lever
 Self-Quadder, 397
 operating lever, 156
 stop pin, 156
 return cam, 155
 shoe, 155
- Power shift of magazines on Models 25**
 and 26, 301-308
- Practice keyboard, 441**
- Pulley (driving) and clutch, 276-278**
 maintenance, 283-285
- Punching, depth of matrix, 40**
- Quadding with the Self-Quadder**
 centered lines, 392
 to left, 392
 to right, 392
- Quick change left-hand vise jaw**
 attachment, 29
- Quick-drop attachment, 209**
 semi quick-drop, 209
- Quick mixing finger key, 310, 317**
- Quick-opening advertising figure knife**
 block, 440
- Rack, furniture, All-Purpose Linotype, 451**
- Rail**
 assembler, 40
 assembling elevator duplex, 18, 93, 95
 assembling elevator matrix support, 93, 96
 distributor box, 252
 maintenance, 261
 first elevator jaw duplex, 108
 stick aligning, All-Purpose Linotype, 461
- Reassembling keyboard, 56**
- Recessed mold, 23, 141**
 liners, 141
- Reed, keyboard, 47, 63**
- Reference cleaner, matrix, Dixon's, 46**
- Reference marking, matrix, 39**
- Regulator, casting interval, All-Purpose Linotype, 452**
- Release mechanism**
 matrix, 9, 47
 spaceband, 85, 87
- Releasing pin, delivery slide, 94, 101**
 adjustment, 96
- Resistance**
 coll, panel box, 172
 failure of, 173
 use of incandescent lamps as, 172
- Retaining pawls, delivery slide, 104**
- Reversible (Hebrew) galley, 228**
- Revolving assembler entrance, 66, 79**
- Revolving front, single distributor**
 Two-in-One Linotypes, 66, 79, 321
- Rheostat, electric metal pot mouthpiece**
 control, 172
- Right hand vise jaw and pump stop, 154**
- Rod, keyboard, 47, 63**
- Roll, keyboard rubber, 47**
 to replace, 54
- Rule form system, All-Purpose Linotype, 464**
- Safeties, All-Purpose Linotype, 467**
- Safety**
 auxiliary line, 116
 first elevator slide, 118
 pawl, adjustment, 382
 second elevator catch, 244
 Two-in-One distributor and channel
 entrance, 341
- Saw**
 Mohr Lino-, 436
 trimmer, slug, All-Purpose Linotype, 450
 maintenance, 472
- Schematic wiring diagrams, 201**
- Screws, vise locking, 123**
- Second elevator, 34, 235, 242**
 adjusting bolt, 242
 adjustment, 383
 bar, 34, 235
 adjustment and care of, 248-249
 link, 235
 plate, 235
 adjustment, 242
 stop pawl, 242
 cam lever, 242
 lever, 235
 safety catch, 244
 starting spring, 242
- Second justification, 130**
- Sectional distributor bar, 291, 294**
- Segments, mold turning, 134, 136**
- Selector handle, Self-Quadder, 395**
- Self-Quadder, 391-409**
 casting blank slugs, 393
 centering lines, 392
 cleaning or repairing vise and vise cap, 403
 control of spaceband driver, 405
 fixed indentation with, 391
 instructions for operating, 392
 justification stop levers, adjustment of, 405
 left hand vise jaw
 detent operating lever, 397
 operating lever, 396
 safety detent, adjustment of, 409
 maintenance, 393-409
 matrix detent, 396
 mold cam lever
 eccentric pin, adjustment of, 405
 "resilient," adjustment of, 407
 pot pump stop lever, 397
 quadding
 to left, 392
 to right, 392

- Self-Quadder—continued**
 selector handle, 395
 toggle
 lever and connecting block, 394
 lock, 399
 cleaning or repairing, 401
 vise control, 394
 rod latch, cleaning or repairing, 402
- Semi quick-drop, 209**
- Series connection**
 of crucible heaters, 168
 of mouth and throat heaters, 168
- Set, automatic ejector, 216**
- Setting the Channel Chooser, 325**
- Shaft, driving, to remove, 283**
- Sharpening**
 back knife, 149
 left- and right-hand trimming knives, 225
- Shift, Blue Streak magazine, 61, 294, 343-353**
- Shift of magazines, Models 25 and 26**
 by hand, 301-302
 by power, 301-308
- Shifter, distributor, 244**
 maintenance, 249
 slide, 246
 maintenance, 249
- Shoe, pot return cam, 155**
- Short circuit, definition of, 175, 178**
- Short finger, delivery slide, 99**
- Side wall, matrix, 40**
- Simple two-letter attachment,**
 26, 43, 114, 116-118
- Single distributor Linotypes, 290-294**
 distributor, 257-263
 box, 250-256
 maintenance, 260-262
 clutch, 264-268
 maintenance, 260-263
 Two-in-One, 320-342, 420
 maintenance, 420
 revolving front, 321
- Single phase circuit, connecting pot to, 176**
- Six-mold disk, 146-147**
 molds for 30-em, 146
 molds for 24½-em, 145
- Sizes of type, 443**
- Slide**
 assembler, 90-92
 maintenance, 92
 delivery
 lubrication of, 107
 removal of, 106
 first elevator, 108, 115
 adjustment of, 112
 filling piece, 114
 gibs, 111
 lubrication of, 122
 safety, 118
 keyboard rod lever, on Two-in-One Linotypes
 Models 8, 14, 25 and 26, 327-332
 Models 29 and 30, 315
 matrix, 36
 mold, *see* Mold Slide
 transfer, 236
 adjustment of travel, 239
 finger, setting of, 238
- Slot**
 matrix bar point, 38, 254
 matrix font, 365
- Slug, 5**
 cooling attachment, All-Purpose
 Linotype, 451
- Slug—continued**
 face surfacer, All-Purpose Linotype, 449
 adjustment, 471
 removing cutter, 472
 failure to eject, 218
 handling, 6
 lever, 226-231
 new style, 229
 old style, 228
 slug adjuster, 231
 vertical, 226
 overhanging, 143
 All-Purpose Linotype, 457
 removing stuck, 218
 saw trimmer, All-Purpose Linotype, 450
 maintenance, 472
- Slugs**
 and leads, thickness of, 443
 weight of, 444
- Spaceband, 4, 85-89**
 box, 85-89
 adjustment, 385
 center bar, adjustment, 385
 maintenance, 87-89
 buffer, 95
 maintenance, 92
 driver, Self-Quadder, control of, 405
 lever,
 adjustment, 384
 pawl, adjustment of, 248
 turn buckle, 242
 maintenance, 43, 412
 release mechanism, 85, 87
 styles of, 85
 to clean, 43
- Special advertising figure mold, 41, 143**
- Special supplies catalog, 442**
- Special tools and supplies, 441**
- Spiral automatics, 258**
 maintenance, 263
- Split magazine, 59**
- Spring**
 keyboard cam yoke, 51
 pot pump lever, 155
 second elevator starting, 242
 vise jaw wedge, 130
- Squirts**
 back, causes of, 208-209
 how to remove, 119
 principal causes, 119
- Star wheel, assembler entrance, 12, 81**
 friction clutch, 83
- Starting**
 and stopping
 manual control of, 281-282
 mechanism, 278-285
 adjustments, 283
 maintenance, 283-285
 pawl, adjustment, 104, 382
 distributor, 267
 lever, adjustment, 382
 mechanism, automatic, 102
- Stick aligning rail and elevator adaptor,**
 All-Purpose Linotype, 461
- Sticks, All-Purpose Linotype, 448**
- Stop, first elevator line, 108**
 maintenance, 122
- Stopping and starting pawl, adjustment, 104**
- Stopping lever, lower, adjustment, 382**
- Straight-line escapement, importance of, 293**
- Strip, keyboard cam stop, 47**
- Stroke of ejector lever, adjusting, 217**
- Stuck slug, removing, 218**

- Stud block, mold locking, 126
 Styles of spacebands, 85
 Supplemental keyboard, 440
 Supplies and parts, ordering, 442
 Supplies and tools, special, 441
 Surfacers, slug face, All-Purpose Linotype, 449
 adjustment, 471
 removing cutter, 472
 Switch
 automatic Micro-Therm temperature control, 197
 fluttering
 dynamic thermometer, 183
 mechanical thermometer, 184
 magnet or "clapper," 171
 humming, 183

 Table top, All-Purpose Linotype, 453
 Teeth, matrix, 35, 38
 care of, 44
 Temperature control
 gas
 thermostat, 159-160
 Micro-Therm, 160-161, 162
 electric
 dynamic thermometer, 168
 mechanical thermostat, 169
 Micro-Therm, 196-206, 210
 Testing
 control panel, 184
 electric metal pot
 lamp in series, 178
 magneto, 178
 for troubles, 178
 lock-up, 206
 panel box, 184
 The Modern Newspaper, 441
 Thermo-Blo mold cooler, 440
 Thermometer, dynamic, 168
 to remove or replace, 193
 Thermostat
 gas metal pot, 159-160
 adjustment, 386
 maintenance, 210
 mechanical, electric metal pot, 164, 169
 maintenance, 211
 to remove or replace, 193-194
 30-em six-mold disk, molds for, 146
 Three phase circuits, connecting pot to, 176
 Three-wire direct current circuit, connecting pot to, 176
 Throat heater, electric metal pot, 167, 168
 and mouth heaters, connected in series, 168
 to remove or replace, 193
 Tie rod, adjustment, 382
 Toggle
 lever and connecting block, Self-Quadder, 394
 lock, Self-Quadder, 399
 cleaning or repairing, 401
 Tools and supplies, special, 441
 Tooth combinations
 and lug charts, 271-275
 on bar and matrices, 269-275
 Transfer
 alignment, adjustment, 246
 first horizontal, 235
 first upward, 234
 lever, adjustment, 247
 second horizontal, 244
 second upward, 242
 Transfer mechanism, 232-249
 distributor shifter, 244
 maintenance, 249
 Transfer mechanism—continued
 distributor shifter—continued
 slide, 246
 maintenance, 249
 elevator transfer
 and spaceband shifter cam, 238
 lever, 237
 first horizontal transfer, 235
 mechanism for, 237
 first upward transfer, 234
 maintenance, 246-249, 417
 second elevator, 235, 242
 adjusting bolt, 242
 bar, adjustment and care, 248-249
 bar plate
 adjustment, 242
 stop pawl, 242
 cam lever, 242
 safety catch, 244
 starting spring, 242
 second horizontal transfer, 244
 second upward transfer, 242
 spaceband lever
 pawl, adjustment, 248
 turn buckle, 242
 strokes of elevator transfers and spaceband levers, 239
 transfer alignment, adjustment, 246
 transfer lever, adjustment, 247
 transfer safety pawl, adjustment, 248
 transfer slide, 236, 239
 adjustment of travel, 239
 finger, setting of, 238
 Transfer slide, 236
 adjustments, 239, 384
 finger, setting of, 238
 Transpositions, matrix, 410
 causes of, 82-84
 Travel of delivery slide, adjustment of, 101-107
 Triangle numbers, matrix, 39, 372
 Trigger, keyboard cam yoke, 47
 Trimming knives
 adjusting left- and right-hand, 223-225, 386
 sharpening, 225
 Trimmer, slug saw, All-Purpose Linotype, 450
 maintenance, 472
 Troubles and testing, 178
 24½-em six-mold disk, molds, 145
 Two-in-One Linotypes, 66-69, 294, 320-342
 arrangement of magazines, 325, 327
 assembler entrance, 79
 Channel Chooser, 321-327
 distributor bar and channel entrance
 positioning mechanism, 332-342
 maintenance, 341-342
 keyboard rod lever slide shifting mechanism
 Models 8 and 14, 25 and 26, 327-332
 Models 29 and 30, 315
 Models 25 and 26, 320
 Models 29 and 30, 320
 Models 31 and 32, 321-327, 332-342
 multiple distributor, 320
 operating sequences with Channel Chooser, 325
 setting the Channel Chooser, 325
 single distributor, 320-342, 420
 Channel Chooser, 321-327
 channel entrance
 and distributor safety, 341
 to open, 342
 to revolve, 342
 maintenance, 418, 420
 revolving front, 66, 79, 321

- Two-Letter**
attachment, simple, 26, 43, 114, 116-118
display or head-letter mold, 142
18- and 24-point matrices, 39
4- to 14-point, 38
- Two-phase circuit, connecting pot to, 176**
- Two-wire direct current circuit, connecting pot to, 176**
- Type**
bodies, decimal equivalents of, 443
individual, on the All-Purpose Linotype, 450
face, aligning on slug, All-Purpose Linotype, 470
measurements, table of, 443
sizes, 443
- Universal adjustable mold, 21, 41, 140**
liners, 140, 143
changing, 140, 141, 143, 146, 151
- Universal ejector, 32, 137, 213-218**
adjusting stroke of lever, 217
blades, 213
maintenance, 216-218
removing, ejector lever adjustable pawl, 217
removing slide, 216
replacing blades, 217
- Universal knife block, 33, 219-225, 440**
maintenance, 223-225, 417
- Upper (oscillating) assembler entrance, 65, 80**
setting, 69
- Upper distributor box**
Models 25 and 26, 296, 297, 298
Models 29 and 30, 314
- Use of incandescent lamps as resistance, 172**
- Vents, mouthpiece, 159**
- Verge, escapement, 62**
- Vertical**
alignment, 129
galley, 226
lever, 285
adjustment, 382
slug lever, 226
transfers, 234, 242
- Vise, 123-132**
and justification, maintenance, 131-132
automatic, 113-114
- Vise—continued**
automatic—continued
adjusting, 113, 120
All-Purpose Linotype, maintenance, 470
disk dog or plunger, adjustment, 384
maintenance, 415
cap, 123
closing lever, 127
frame, 123-126
jaws, 126, 127, 128
adjustment, 131, 386
and justification, maintenance, 131-132
and vise cap, Self-Quadder, cleaning or repairing, 403
control, Self-Quadder, 394
rod latch, cleaning or repairing, 402
left-hand quick change attachment, 29
left-hand, safety detent, Self-Quadder, Adjustment of, 409
wedge, 129
adjusting, 131
spring, 130
justification bar, 128
locking screws, 123
maintenance, 415
- Wall, matrix side, 40**
- Wedge, vise jaw, 129**
- Wedge spring, vise jaw, 130**
- Wedges and dial, aligning, All-Purpose Linotype, 452**
- Weight, keyboard key, 47**
- Weights of slugs, 444**
- Wiper**
back mold, 144
care of, 151
front mold, 145
knife, 118
mold, maintenance, 415
pot mouthpiece, 42-em Linotype, 379, 439
maintenance, 416
- Wiring diagrams, 174, 184, 186-192, 201, 202, 204**
control panel, electric metal pot, 184
definitions, 174-175
Micro-Therm controlled electric metal pot, 199, 200, 201
- Yoke, keyboard cam, 47**
- Yokes and cams, keyboard, cleaning, 53**